

Safety Warnings and Precautions for Device

Precautions for use of battery

1. If the battery of device is removable, do not apply improper pressure when installing the battery, otherwise, battery leakage, overheating, burst or fire may be caused;
2. If the battery of device is a non-removable, please do not remove it by yourself, otherwise, device device and safety problems may be caused;
3. Do not weld the battery connector. After the battery is removed from the device, do not put it together with metal objects such as necklaces, and please put it safely with non-conductive materials or casings; if the conductive material contacts the exposed connector, battery damage, burn or personal injury may be caused;
4. Do not squeeze or puncture the battery (for example: do not pierce the battery with sharp objects such as needles; do not put it in the back pocket of your trousers, so as not to squeeze the battery when sitting down), otherwise, battery leakage, overheating, explosion and fire may be caused;
5. If the battery liquid touches the skin or clothing, skin burns may be caused; please immediately rinse with water and soap, and seek medical attention as soon as possible if necessary;
6. If there is any abnormal phenomenon in battery during use, charging and storage, such as high temperature, discoloration, deformation, bulging and leakage, please stop using it and replace it with a new one to prevent safety problems;
7. If battery liquid enters the eyes, there is a risk of blindness; at this time, do not rub your eyes with your hands, please rinse with water and then go to the hospital as soon as possible;
8. Do not disassemble or modify the battery, otherwise, battery leakage, overheating, burst and fire may be caused;
9. Do not use or put the battery in a place with high temperature such as the places near an open flame or a heater, otherwise, battery leakage, overheating, burst and fire may be caused;
10. If the battery is leaking liquid or emitting a strange smell, please remove it from the open flame immediately to avoid fire and explosion;
11. Please protect the battery from moisture, otherwise, battery overheating, smoke or corrosion may be caused;
12. Do not use or put the battery in places at high temperature such as the places exposed to direct sunlight or near a car, otherwise, liquid leakage and overheating may be caused, which may reduce performance and shorten service life; please put the battery in a well-ventilated place far away from direct sunlight;
13. Do not use the device in a high-voltage environment or directly connect the battery to the mains supply, otherwise, an explosion accident may be caused due to a short circuit arising therefrom;
14. Do not throw the battery into the fire, otherwise, battery may catch fire or burst; do not throw the used battery into the general household garbage; please dispose of the battery in accordance with the prescribed instructions in the place where regulations on the disposal of used batteries are clearly specified.

Precautions for charging

1. Please charge with the standard data cable and charger;
2. Please charge under the power supply voltage specified by the matching charger, otherwise,

leakage, fire and damage to device and charger may be caused when charging under other voltages;

3. Do not use a power socket that is not suitable for the charger plug. Be sure to ensure that the charger socket and slot are connected stably, otherwise, there may be a risk of fire;
4. Please do not charge the device with the charger or power cord that has been damaged, otherwise, electric shock, smoke, fire and device damage may be caused;
5. Please do not put the water container next to the charger to prevent charger overheating, leakage and failure caused due to spilled water;
6. If the charger comes into contact with water or other liquids, please immediately unplug the power socket or the charger from the socket to prevent overheating, fire, electric shock and charger damage;
7. Please do not use the charger in places with high humidity such as bathroom, otherwise, electric shock, fire and damage to charger may be caused;
8. Please do not remove or modify the charger, otherwise, personal injury, electric shock, fire and damage to charger may be caused;
9. Please do not touch the charger, wire and power socket with wet hands, otherwise, electric shock may be caused;
10. Do not put heavy objects on the power cord or modify the wire, otherwise, electric shock and fire may be caused;
11. Grasp the charger when pulling out the plug, because the wire may be damaged when pulling the power cord, causing electric shock and fire;
12. Please pull out the power plug from the socket before cleaning and maintenance;
13. Please do not charge in the following places: places exposed to direct sunlight; places where the temperature is too high or too low; humid or dusty places or places with great vibration (otherwise, failures may be caused);

Precautions for scanning

1. During the scanning process of device, do not look directly at the scanner, otherwise, eye damage may be caused;
2. When the device is not working, please turn off the fill light and laser light, otherwise, high temperature damage may be caused and the service life of device may be reduced.

Precautions for use of medical device

1. In medical places where the use of device is prohibited, please follow the instructions and regulations of the place;
2. The device needs to be cleaned regularly with the specified cleaning solution, otherwise, device exceptions may be caused; please keep the device in a non-charging and off state during the cleaning process;
3. Please pay attention to the settings of ringtone, volume and vibration of device for patients with heart disease, so as not to affect others.

Precautions for use of explosion-proof device

1. The device must be used in a scene that meets the conditions for explosion-proof certification;
2. It is strictly forbidden to charge the device in explosion-proof areas.
3. The charging of device must be implemented in strict accordance with the management regulations.

Precautions for operating environment

1. The device may have different waterproof levels for different specifications, but it shall not be operated in extremely high temperature, extremely low temperature or wet environment;
2. Do not use the device in a place that is dusty, humid, dirty or close to magnetic fields, otherwise, internal circuit failure may be caused to the device;
3. During thunderstorms, do not use the device while charging or outdoors to avoid lightning strikes or other injuries;
4. Please abide by the provisions of the international regulations on radio frequency radiation, and use the device accessories designated by our company.

Precautions for repair and maintenance

1. When foreign objects such as liquids and metal chips are attached to the surface of device screen, wipe them off as soon as possible;
2. Do not hit, vibrate or throw the device violently to avoid device failure and fire;
3. Do not squeeze or twist the device (for example: use the device as a seat cushion and sit on it, put it in the back pocket of the trousers, or twist the device in forward and reverse directions, etc.), because excessive deformation may result in cracks or damages to the display screen;
4. Do not put device, battery or charger in and around heating device or high-voltage device (such as microwave ovens, baking ovens, radiators, etc.), otherwise, accidents such as circuit damage, fire and explosion may be caused;
5. It is forbidden to click and draw lines on the surface of display screen with sharp objects; it is forbidden to press the surface of the display screen with heavy objects, or even press a certain fixed position of the display screen for a long time;
6. Do not put the device in a place with high temperature, high humidity or a lot of dust, otherwise, failures may be caused;
7. Please put the device, battery and charger in a place out of the reach of children, so as to prevent children from using it as a toy and resulting in personal injury;
8. Do not place the device on an uneven or unstable table, to prevent failure or damage caused due to falling;
9. Battery and charger are not waterproof, please do not use them in places with high humidity, and meanwhile protect it from being wet by rain;
10. Do not paint the device, because paint may block the moving parts of device and prevent normal use;
11. Dirty sockets may cause poor contact and leakage of charger, so that it cannot be recharged; please clean it regularly;
12. Please clean the device (including scanning window, camera window, etc.) with a soft dry cloth, do not scratch with sharp objects, please turn off the device and not charge it during the cleaning process;
13. The display screen may be damaged after pressing hard on the display screen. Do not tap the screen with a stylus pen for resistive touch screen, to prevent scratching or damaging the screen;

14. If the device and its parts and accessories do not work properly, please contact the authorized service agency nearby, and the personnel of service center will offer help.

Precautions for storage environment

1. Please keep the device away from magnetic devices, such as magnetic cards and floppy disks, because the radiation from the device may erase the information saved on the magnetic device;
2. Do not place device, battery and charger in the appliances with strong electromagnetic fields, such as induction cookers and microwave ovens, otherwise, circuit failure, fire or explosion may be caused;
3. Do not put device, battery and charger in the areas with high temperature or too low temperature, otherwise, failure, fire or explosion may be caused to device, battery and charger;
4. Do not put sharp metal objects such as pins near device earpiece, because device earpiece may draw these objects under the action of magnetism, which may cause injury when using the device;
5. Please protect the device, battery and charger from strong shock or vibration, so as to avoid battery leakage, device failure, overheating, fire or explosion.

Precautions for traffic safety

1. When driving the vehicle, please abide by the relevant regulations of the region or the state. Do not use the device while driving, so as not to hinder safe driving and cause traffic accidents;
2. Do not place the device above the car airbag or in the area within the reach of airbag after being deployed, otherwise, the device will be subjected to strong external force when the airbag expands or ruptures, which may cause serious injury to the occupants of the car;
3. When taking an airplane, please abide by the relevant rules and regulations of the airline company. In areas of airport where the use of device is prohibited, please turn off the device to prevent the wireless signal of device from interfering with the aircraft control signal.

Precautions for children's health

1. Please keep the device, battery and charger out of the reach of children, and do not allow children to use the device, battery and charger without supervision of adults;
2. Do not allow children to put the battery in their mouths, because the electrolyte may cause poisoning;
3. Do not allow children to touch the small parts of the device, otherwise, children may swallow parts, resulting in suffocation and blockage of esophagus and other injuries.